

PECORA DECK 8013QZ PEDESTRIAN (Decorative Quartz Aggregate Option)

Application Instruction:

- A. Surface preparation.
- B. Prime concrete with Pecora P-801-VOC (<100g/L) **or** P-808 (<450g/L)¹ primer at 250 to 350 square feet per gallon.
- C. Apply base coat of Pecora 802 Base Coat at 50 square feet per gallon using a ¼" notched squeegee. (Must apply base coat the same day as priming, otherwise reprime.)
- D. Allow base coat to cure overnight (minimum).
- E. Apply top coat of Pecora 806 Top Coat at 100 square feet per gallon using a ⅛" notched squeegee.
- F. Broadcast 30-50 mesh rounded decorative quartz aggregate to refusal (approx. 50 lb./per 100 square feet) while the Pecora 806 Top Coat is still fluid.
- G. Allow the 806 Top Coat to cure overnight. Sweep off excess aggregate.
- H. Apply two (2) coats of Pecora-Deck 806 Clear Top Coat:
 - a. 1st Coat: Apply 806 at 160 square feet per gallon (10 wet mils) using a flat squeegee. Backroll for even coverage with a ¼" nap roller, if necessary. Allow to cure and become firm & tacky (minimum 4-6 hours).
 - b. 2nd Coat: Apply 806 at 160 square feet per gallon (10 wet mils) using a flat squeegee. Backroll for even coverage with a ¼" nap roller, if necessary.
- I. Allow Top Coat to cure 24-48 hours prior to opening to traffic.

Installed Thickness: mils (millimeters) excluding aggregate

	<u>Wet mils (mm)</u>	<u>Dry mils (mm)</u>
Base Coat	32 (.81)	26 (.67)
Top Coat	16 (.40)	11 (.28)
Clear Top Coat	10 (.25)	6 (.15)
Clear Top Coat	10 (.25)	6 (.15)
Total	68 (1.71)	49 (1.25)

CAUTION: Pecora-Deck 800 forms a non-breathing membrane and therefore is generally not used on-grade or outside on concrete surfaces poured over vapor barriers (such as unvented metal decks or between slab membranes). Consult Pecora Technical Service for applications on-grade, over unvented metal decks or concrete with between slab membranes.

¹ Check local VOC regulations for product compliance prior to installing deck coating primer.