



114: DECK-TO-WALL EXPANSION JOINT with PECORA DYNASPAN




- NOTES:
- SEE HB1100-SA APPLICATION GUIDE for SYSTEM COAT and COATING THICKNESSES and INSTALLATION INSTRUCTIONS.
 - CONTACT PECORA TECHNICAL SERVICE FOR COMPONENTS and SIZING OF DYNASPAN EXPANSION JOINT SYSTEM.

116: DECK-TO-WALL EXP. JT. (COMPRESSIBLE JT FILLER)




- NOTES:
- SEE HB1000 APPLICATION GUIDE for SYSTEM COAT and COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

124: SCUPPER DETAIL




- NOTES:
- SEE HB1000 APPLICATION GUIDE for SYSTEM COAT and COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

115: DECK-TO-WALL EXPANSION JOINT (FLEXIBLE FLASHING)



- NOTES:
- SEE HB1000 APPLICATION GUIDE for SYSTEM COAT and COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

117: DECK-TO-WALL STATIC JOINT



- NOTES:
- SEE HB1000 APPLICATION GUIDE for SYSTEM COAT and COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

NOTE:

1. SEE PECORA-DECK HB1000 APPLICATION MANUAL for SYSTEM COATS, COATING THICKNESSES & AGGREGATE SIZES AND INSTALLATION INSTRUCTIONS.