



106: SURFACE-MTD POST (POST INSTALLED FIRST)




NOTES:
- SEE PECORA DECK 800 SERIES APPLICATION GUIDE for SYSTEM COAT, COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

106A: SURFACE-MTD. POST (COATING INSTALLED FIRST)




NOTES:
- SEE PECORA DECK 800 SERIES APPLICATION GUIDE for SYSTEM COAT, COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

107: FLOOR PENETRATION TREATMENT




NOTES:
- SEE PECORA DECK 800 SERIES APPLICATION GUIDE for SYSTEM COAT, COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

108: APPLICATION AROUND DECK DRAIN




NOTES:
- SEE PECORA DECK 800 SERIES APPLICATION GUIDE for SYSTEM COAT, COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

109: TREATMENT AROUND DECK DRAIN



NOTES:
- SEE PECORA DECK 800 SERIES APPLICATION GUIDE for SYSTEM COAT, COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

110: NEW / RESET STONE & METAL THRESHOLDS



NOTES:
- SEE PECORA DECK 800 SERIES APPLICATION GUIDE for SYSTEM COAT, COATING THICKNESSES and INSTALLATION INSTRUCTIONS.

NOTE:
1. SEE PECORA-DECK 800 SERIES APPLICATION MANUAL for SYSTEM COATS, COATING THICKNESSES & AGGREGATE SIZES AND INSTALLATION INSTRUCTIONS.