

## PECORA DECK 8013 PEDESTRIAN

**Application Instruction:**

- A. Surface preparation.
- B. Prime concrete or plywood with Pecora P-801-VOC (<100g/L) or P-808 (<450g/L)<sup>1</sup> primer at 250 to 350 square feet per gallon. Allow primer to dry 1 – 8 hours.
- C. Apply base coat of Pecora 802 Base Coat at 50 square feet per gallon using a ¼” notched squeegee. (Must apply base coat the same day as priming, otherwise reprime.)
- D. Allow base coat to cure overnight (minimum).
- E. Apply top coat of Pecora 806 Top Coat at 100 square feet per gallon using a 1/8” notched squeegee.
- F. Broadcast 16-30 mesh aggregate<sup>2</sup> at 10-15 pounds per 100 square feet while the Pecora 806 Top Coat is still fluid.
- G. Immediately back roll and completely encapsulate the aggregate with a ½” nap roller.
- H. Cure 806 Top Coat for 48-72 hours prior to opening completed system to traffic.

**Installed Thickness:**      mils (millimeters) excluding aggregate

	<u>Wet</u>	<u>Dry</u>
Base Coat	32 (.81)	26 (.67)
Top Coat	16 (.40)	11 (.28)
<b>Total</b>	<b>48 (1.21)</b>	<b>37 (.95)</b>

**CAUTION:** Pecora Deck 800 forms a non-breathing membrane and therefore is generally not used on-grade or outside on concrete surfaces poured over vapor barriers (such as unvented metal decks or between slab membranes). Consult Pecora Technical Service for applications on-grade, over unvented metal decks or concrete with between slab membranes.

<sup>1</sup> Check local VOC regulations for product compliance prior to installing deck coating primer.

<sup>2</sup> Employees using crystalline silica must wear an approved respirator if the exposure is above the permissible exposure level. Consult manufacturer’s guidelines for safety practices.