

PECORA DECK 8213 ELEVATED POOL AND TENNIS DECK SYSTEM

Application Instructions:

- A. Surface preparation
- B. Prime concrete with Pecora P-801-VOC (<100g/L) or P-808 (<450g/L)¹ primer at 250 to 350 square feet per gallon. Allow primer to dry 1 – 8 hours.
- C. Apply Pecora 802 Base Coat at 50 square feet per gallon using a ¼” notched squeegee. (Must apply base coat the same day as priming, otherwise reprime.)
- D. Allow base coat to cure overnight (minimum.)
- E. Apply Pecora 806 Top Coat at 200 square feet per gallon using a flat squeegee. Backroll for uniformity with a ½” nap roller.
- F. Immediately broadcast 80 - 100 mesh aggregate² at 25 pounds per 100 square feet. Completely and uniformly cover all of the Pecora 806 Top Coat. Allow to cure overnight (minimum). Sweep off excess sand.
- G. Repeat step E & F.
- H. Apply a final top coat of Pecora 806 Top Coat at 125 square feet per gallon using a 1/8” notched squeegee. Backroll for uniformity with a ½” nap roller.

INSTALLED THICKNESS: mils (millimeters) excluding aggregate

	<u>WET</u>	<u>DRY</u>
Base Coat	32 (.81)	25 (.67)
1 st . Sand Coat	8 (.20)	6 (.16)
2 nd . Sand Coat	8 (.20)	6 (.16)
Top Coat	12 (.30)	9 (.23)
Total	60 (1.51)	46 (1.2)

CAUTION: Pecora-Deck 800 forms a non-breathing membrane and therefore is generally not used on-grade or outside on concrete surfaces poured over vapor barriers (such as unvented metal decks or between slab membranes.) Consult Pecora Technical Service for applications on-grade, over unvented metal decks or concrete with between slab membranes.

¹ Check local VOC regulations for product compliance prior to installing deck coating primer.

² Employees using crystalline silica must wear an approved respirator if the exposure is above the permissible exposure level. Consult manufacturer’s guidelines for safety practices.